

Safety Decal Placement for Axial Fans & Heaters

Safety decals and shields are mounted whenever possible at factory.

Yearly and prior to equipment use, please check that all decals are in place according to these drawings and in good legible condition. To order a replacement decal or shield free of charge, contact your dealer or **Sukup Manufacturing, Co. - P.O. Box 677 - Sheffield, IA, 50475**. Please specify computer number.

IMPORTANT ! The following safety decals should be mounted on your equipment as shown below. If suggested locations are not clearly visible, place safety decals in a more suitable area. Never cover up any existing safety decals.

Make sure location area for decal is free from grease, oil and dirt. Remove backing from decal and place in proper position.

1. **WARNING - L0281** - Safe operation decal.



2. **WARNING - L0165** - Disconnect Electricity; Bleed gas



3. **WARNING - L0166** - Keep guards and shields in place; Disconnect electricity; Check fan blade for tightness.



4. **DANGER - L0204** - Close service door.



The numbers on the drawings below refer to the location of the safety decals listed above.

